


Points to Note on Turning ON/OFF the Power Switch

- Do not turn OFF the Main Power Switch while the progress bar (to be displayed when the power is turned ON) is displayed, which indicates access to the HDD.
- Be sure to turn OFF the Main Power Switch to cut the power (there is no need to perform the shutdown sequence which has been performed with the conventional machines).
- After turning OFF the power (after turning OFF the Main Power Switch), do not turn ON the Main Power Switch unless the screen disappears.
- Do not turn OFF the power during downloading.

Control Panel

Control Panel



[1]	Main Menu Key	[10]	Settings/registration Key
[2]	Custom Menu Key	[11]	Check Counter Key
[3]	Check/Stop Status Key	[12]	Stop Key
[4]	Volume Adjustment Key	[13]	Operation Pen
[5]	Brightness Adjustment Key	[14]	ID Key
[6]	Touch Panel Display	[15]	Clear Key
[7]	Control Panel Power Switch (Sub-power)	[16]	Reset Key
[8]	USB Slot	[17]	Start Key
[9]	Numeric Key		