


Control Panel

Control Panel




F-1-14

- [1] Main Menu Key
- [2] Custom Menu Key
- [3] Check/Stop Status Key
- [4] Volume Adjustment Key
- [5] Brightness Adjustment Key
- [6] Touch Panel Display
- [7] Energy Saver key.
- [8] USB Slot
- [9] Numeric Key
- [10] Settings/registration Key
- [11] Check Counter Key
- [12] Stop Key
- [13] Operation Pen
- [14] ID Key
- [15] Clear Key
- [16] Reset Key
- [17] Start Key

T-1-15

Main Menu

Menu screen



F-1-15

- [1] Copy
- [2] Scan and Send
- [3] Scan and Save
- [4] Access Stored F
- [5] Fax/I-Fax Inbox
- [6] Secured Print
- [7] Introduction to Useful Features
- [8] Remote Scanner
- [9] Shortcut to Settings/Registration

T-1-16