


# Control Panel


## Control Panel



F-1-17

[1]	Main Menu Key	[10]	Numeric Key
[2]	Custom Menu Key	[11]	Settings/registration Key
[3]	Check/Stop Status Key	[12]	Check Counter Key
[4]	Volume Adjustment Key	[13]	Stop Key
[5]	Brightness Adjustment Key	[14]	Operation Pen
[6]	Touch Panel Display	[15]	ID Key
[7]	Control Panel Power Switch (Sub-power)	[16]	Clear Key
[8]	Energy Saver Key	[17]	Reset Key
[9]	USB Slot	[18]	Start Key

## Main Menu



F-1-18

[1]	Copy
[2]	Scan and Send
[3]	Scan and Store
[4]	Access Stored Files
[5]	Fax/Fax Inbox
[6]	Secured Print
[7]	Remote Scanner
[8]	Shortcut to Settings/Registration
[9]	Introduction to Useful Features