



Main Menu



No.	Name
[1]	Settings/Registration
[2]	Menu
[3]	Energy Saver
[4]	Log In, Log Out
[5]	Home
[6]	Timeline
[7]	Stop
[8]	Counter/Device Information
[9]	Status Check
[10]	Numeric keys ([0] to [9], [*], [#])
[11]	C (Clear)
[12]	Reset
[13]	Stop
[14]	Start

Service Buttons



Reference figure (Rear side of Control Panel)