


No.	Name	No.	Name
[12]	Drum Unit (Bk)	[27]	Fixing Assembly
[13]	Hopper Unit (Bk)	[28]	Duplex Feed Unit
[14]	Developing Assembly (Bk)	[29]	Fixing Feed Unit
[15]	Reader Unit		

Control Panel



No.	Name	No.	Name
[1]	[Settings/Registration] key	[9]	[Start] key
[2]	Numeric keys	[10]	Main Power indicator
[3]	[Energy Saver] key	[11]	Error indicator
[4]	[Counter/Device Information] key	[12]	Processing/Data indicator
[5]	Brightness Adjustment key	[13]	[Reset] key
[6]	Settings key	[14]	ID (Log In/Out) key
[7]	[Clear] key	[15]	NFC (If equipped with NFC Kit-B1)
[8]	[Stop] key	[16]	Touch panel display